



Installation Instructions for SYCOM Wall Mount Protectors

1. Plug the SYCOM protector directly into the AC wall socket.
2. If equipped with telephone protection, connect telephone line into the input telco jack using supplied telco cord. Connect telephone cable from the equipment into the output jack.
3. Connect the equipment line cords into the AC receptacles of the SYCOM protector
4. If equipped with Coax cable protection, connect the cable from the outside to the input jack and the TV cable to the output jack.

Installation Instructions for SYCOM Plug-in Strip Protectors

1. Connect the equipment to the protector using the existing telephone cord to connect to the output jack.
2. Connect the AC cords of the equipment to the plug-in protector
3. Connect the surge protector cord AC wall outlet jack
4. Turn on the protector using the on/off switch of the protector
5. The indicator lights should be on after the unit has been installed.
6. If the unit has Coax cable protection, connect the cable from the outside to the input jack and the TV cable to the output jack

Sycom Surge, Inc.
12929 44th St N
Clearwater, FL 33762

(800) 622-9904
www.sycomsurge.com